

Microplastic-free microcapsules using interfacial self-assembly of bis-urea molecules

Siddhant Bhutkar, Pierre-Eric Millard,
Jon A. Preece, Zhibing Zhang



UNIVERSITY OF
BIRMINGHAM



We create chemistry



FORMULATION
ENGINEERING CDT



Engineering and
Physical Sciences
Research Council



Annual Meeting
AND Exposition
JULY 8-12, 2024 • BOLOGNA, ITALY

INTEGRATING
Delivery Science
ACROSS DISCIPLINES




Background



UNIVERSITY OF
BIRMINGHAM

BASF
We create chemistry



Microcapsules are widely used in these commercial formulations for:

- Protection, increasing shelf-life
- Easier handling
- **Controlled release**

Capsule shell from **synthetic polymers**, highly crosslinked, non-biodegradable – **MICROPLASTIC**




Solution: Using **small molecules**, self-assembled with **non-covalent** hydrogen bonds to form the shell

Strategy



Step 1


- Stable oil-in-water emulsion



- Oil Phase
 - Active Ingredient
 - Isocyanate


Step 2

- Amine addition




Step 3

- Reaction and bis-urea formation at the interface



Step 4

- Self-assembly at the interface to form the shell



***In-situ* generation and interfacial self-assembly of bis-urea molecules**




Observations



UNIVERSITY OF
BIRMINGHAM



BASF
We create chemistry

▪ Morphology



Reduce aggregation and porosity

▪ Aggregation





Improvements




UNIVERSITY OF
BIRMINGHAM

BASF
We create chemistry

▪ Laponite[®] nanodiscs



Without
Laponite[®]





With
Laponite[®]


Volume (%)

Particle Size (μm)

▪ TEM Cross-section



Without Laponite[®]




With Laponite[®]

Release Study




- Accelerated release test in 36% aq. propanol (v/v)



$$y = a \left(1 - e^{-\frac{t}{\tau}} \right)$$

y: cumulative release (weight fraction)
t: time
a: dimensionless constant
 τ : characteristic release time

	τ (min)
Unencapsulated oil	47
Capsules made using PVA only	634
Capsules made using PVA and Laponite [®]	1017





Mechanical Strength




UNIVERSITY OF
BIRMINGHAM

BASF
We create chemistry



Capsule dia = 20 μm



	Rupture tension ($\mu\text{N}/\mu\text{m}$)
Capsules made using PVA only	7 ± 1
Capsules made using PVA and Laponite [®]	23 ± 2

$$\text{Rupture tension} = \frac{F_r}{d}$$

F_r = Rupture force
 d = capsule diameter

Commercial non-degradable Capsules,
Rupture tension
7 to 111 $\mu\text{N}/\mu\text{m}$





Guinebretiere et. al (2008), WO2008066773A2

Improved Mechanical Strength





UNIVERSITY OF
BIRMINGHAM

BASF
We create chemistry



	Rupture tension ($\mu\text{N}/\mu\text{m}$)
Capsules made using PVA only	7 ± 1
Capsules made using PVA and Laponite [®]	23 ± 2
Capsules made using new molecule	56 ± 4

▪ Methyl Cellulose as an emulsifier



Commercial non-degradable Capsules,
Rupture tension
7 to 111 $\mu\text{N}/\mu\text{m}$


Guinebretiere et. al (2008), WO2008066773A2

Impact



UNIVERSITY OF
BIRMINGHAM

BASF
We create chemistry



Global microcapsule market **US\$ 11 bn**

- Novel method to synthesize microplastic free microcapsules
- A facile one-pot, *in-situ* process under benign conditions
- Successful encapsulation of commercial herbicide

(12) INTERNATIONAL APPLICATION PUBLISHED UNDER THE PATENT COOPERATION TREATY (PCT)

(19) World Intellectual Property
Organization
International Bureau

(43) International Publication Date
22 February 2024 (22.02.2024)



(10) International Publication Number
WO 2024/038046 A1

- A plethora of small molecules to test
- Industrial viability: using existing equipment

Acknowledgements

- MCAP research group, UoB
- Centre for Electron Microscopy, UoB
- BASF SE, Ludwigshafen, Germany
- Formulation Engineering CDT

Feel free to get in touch:

spb006@student.bham.ac.uk




Siddhant Bhutkar

<https://www.linkedin.com/in/siddhant-bhutkar/>



UNIVERSITY OF
BIRMINGHAM

BASF
We create chemistry



Engineering and
Physical Sciences
Research Council



FORMULATION
ENGINEERING CDT

